




Capture pencil of rays  
- all rays through a single point




Pinhole projection model.



Dimensionality reduction (3D  $\rightarrow$  2D image)

- preserved: straight lines, incidence
- not preserved: angles, lengths







Fronto - parallel planes

- All points are at fixed depth  $z$
- scaled  $\frac{f}{z}$ , angles & ratios of length / region preserved


Vanishing points

All parallel lines converge to a vanishing point

Exception: directions parallel to the image plane



Comparing heights / Measure heights



## Homogeneous coordinates

- Nonlinearity:  $(x, y, z) \rightarrow (f\frac{x}{z}, f\frac{y}{z})$

$$(x, y) \Rightarrow \begin{bmatrix} x \\ y \\ 1 \end{bmatrix}$$

(image)

$\uparrow$   
division  $z$  is non-linear

$$(x, y, z) \Rightarrow \begin{bmatrix} x \\ y \\ z \\ 1 \end{bmatrix}$$

(scene)

$$\begin{bmatrix} x \\ y \\ w \end{bmatrix} \Rightarrow (\frac{x}{w}, \frac{y}{w})$$

$$\begin{bmatrix} x \\ y \\ z \\ w \end{bmatrix} \Rightarrow (\frac{x}{w}, \frac{y}{w}, \frac{z}{w})$$

- invariant to scaling

$$k \begin{bmatrix} x \\ y \\ w \end{bmatrix} = \begin{bmatrix} kx \\ ky \\ kw \end{bmatrix} \Rightarrow \begin{bmatrix} \frac{kx}{kw} \\ \frac{ky}{kw} \end{bmatrix} = \begin{bmatrix} \frac{x}{w} \\ \frac{y}{w} \end{bmatrix}$$

## Perspective Projection Matrix.

Projection: a matrix multiplication with homogeneous coordinates

$$\left( \begin{bmatrix} f & 0 & 0 & 0 \\ 0 & f & 0 & 0 \\ 0 & 0 & 1 & 0 \end{bmatrix} \right) \begin{bmatrix} x \\ y \\ z \\ 1 \end{bmatrix} = \begin{bmatrix} fx \\ fy \\ z \end{bmatrix} \Rightarrow (f\frac{x}{z}, f\frac{y}{z})$$

$\downarrow$   
projection matrix

- Orthographic projection (parallel projection)


$$\left( \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \right) \begin{bmatrix} x \\ y \\ z \\ 1 \end{bmatrix} = \begin{bmatrix} x \\ y \\ 1 \end{bmatrix} \Rightarrow (x, y)$$

### Quiz-01) 3D-to-2D


- When the 3D world dimension reduces to 2D, what properties are preserved?
  - Straight lines
  - Incidence
  - Angles
  - Lengths

### Quiz-02) Constructing the vanishing point of a line

- In the figure below, there are two blue parallel lines, perpendicular to the image plane. Draw how the lines look like in the image plan and discuss the result.




Q: How to determine which point is the cross point of line and plane?



### Quiz-03) Orthographic projection

- Perform Orthographic projection to each 3D cube in 3D below and show the result in 2D



$\Rightarrow$  from  $\Rightarrow$  look to the image

$$\begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} 0 \\ 1 \\ 1 \end{bmatrix} = \begin{bmatrix} 0 \\ 1 \\ 1 \end{bmatrix} \Rightarrow (0, 0)$$

$$(0, 0, 1) \Rightarrow (0, 0)$$

$$(0, 1, 1) \Rightarrow (0, 1)$$

$$(1, 0, 0) \Rightarrow (1, 0)$$

$$(1, 1, 0) \Rightarrow (1, 1)$$

$$(0, 0, \sqrt{2}) \Rightarrow (0, 0)$$

$$(0, 2, \sqrt{2}) \Rightarrow (0, 2)$$

$$(-1, 1, 0) \Rightarrow (-1, 1)$$

$$(1, 1, 0) \Rightarrow (1, 1)$$

### Quiz-04) Projection matrix (2D-to-2D)

- Given two point sets:
  - $x = (x_1, \dots, x_4) = ((u_1, v_1), \dots, (u_4, v_4)) = ((0,260), (640,260), (0,400), (640,400))$
  - $x' = (x'_1, \dots, x'_4) = ((u'_1, v'_1), \dots, (u'_4, v'_4)) = ((0,0), (400,0), (0,640), (400,640))$

Find the perspective projection matrix  $P$  such that  $x' = Px$

$$0 \cdot x_1 + 260 \cdot x_2 + x_3 = 0$$

$$640 \cdot x_1 + 260 \cdot x_2 + x_3 = 400$$

$$0 \cdot x_1 + 400 \cdot x_2 + x_3 = 0 \Rightarrow x_3 = 0$$

$$640 \cdot x_1 + 400 \cdot x_2 + x_3 = 400 \Rightarrow x_3 = 400 - 640 \cdot x_1 = 0$$

$$260 \cdot x_5 + x_6 = 0$$

$$640 \cdot x_4 + 260 \cdot x_5 + x_6 = 0$$

$$400 \cdot x_5 + x_6 = 640 \Rightarrow x_5 = \frac{640}{160} = 4 \quad x_6 = -960$$

$$640 \cdot x_4 + 400 \cdot x_5 + x_6 = 640$$

$$\begin{bmatrix} x_1 & x_2 & x_3 \\ x_4 & x_5 & x_6 \\ 0 & 0 & 1 \end{bmatrix} \quad \left\{ \begin{array}{l} x_1 = \frac{5}{8} \\ x_2 = 0 \\ x_3 = 0 \end{array} \right. \quad \left\{ \begin{array}{l} x_4 = 0 \\ x_5 = 4 \\ x_6 = -960 \end{array} \right.$$

$$P = \begin{bmatrix} \frac{5}{8} & 0 & 0 \\ 0 & 4 & -960 \\ 0 & 0 & 1 \end{bmatrix}$$

$$\begin{bmatrix} C_{00} & C_{01} & C_{02} \\ C_{10} & C_{11} & C_{12} \\ C_{20} & C_{21} & C_{22} \end{bmatrix} \begin{bmatrix} u \\ v \\ 1 \end{bmatrix} = \begin{bmatrix} u' \\ v' \\ 1 \end{bmatrix}$$

$$C_{00}u + C_{01}v + C_{02} = u'$$

$$C_{10}u + C_{11}v + C_{12} = v' \Rightarrow$$

$$C_{20}u + C_{21}v + C_{22} = 1$$

$$\frac{C_{00}u + C_{01}v + C_{02}}{C_{20}u + C_{21}v + C_{22}} = u'$$


$$\frac{C_{10}u + C_{11}v + C_{12}}{C_{20}u + C_{21}v + C_{22}} = v,$$

Shrinking the aperture


- aperture smaller  $\Rightarrow$  clearer image
- aperture too small:  $\begin{cases} \text{less light goes through} \\ \text{diffraction effects} \end{cases}$

Thin lens model:

- rays passing through the center are not deviated  
(pinhole model still holds)
- all rays // optical axis pass through focal point
- all // rays converge to points on the focal plane




Thin lens formula




Depth of field (DoF)

- a specific distance at which objects are "in focus"



- $\begin{cases} \text{large aperture} = \text{small DoF} \\ \text{small aperture} = \text{large DoF} \end{cases}$

## Field of View (FOV)



$$\varphi = \tan^{-1} \left( \frac{d}{2f} \right)$$


The dolly zoom

- adjusting the focal length while the camera moves away from the subject

Lens flaws


- spherical aberration
- chromatic aberration

## Modern photography pipeline



Demosaicing : estimation of missing components from neighboring values

- produce full RGB image from mosaiced output



Bilinear neighboring :

① green channel

$$G_1 \rightarrow G_? \leftarrow G_3 \quad G_? = \frac{G_1 + G_2 + G_3 + G_4}{4}$$

$G_2$   
↓  
 $G_1 \rightarrow G_? \leftarrow G_3$   
↑  
 $G_4$

② red / blue channel



Digital Camera artifacts

- noise
- in-camera processing
- compression
- blooming
- color artifacts

}

How to remove ?  
filtering

A Bayer filter mosaic is a color filter array (CFA) for arranging RGB color filters on a square grid of photons. Figure 1 shows a raw image obtained by the Bayer pattern CFA where each pixel includes the R or G or B value. Perform image demosaicing to the image region in orange box using bilinear interpolation and provide each pixel's RGB value, (R, G, B) of the  $3 \times 3$  image.




Figure 1

$$\begin{matrix}
 2 & 10 & 0 \\
 4.5 & 5 & \\
 2.325 & 4.456 & \\
 2.5 & 2.875 & 3 \\
 2.125 & 2.175 & 0 \\
 2 & 2 & \\
 2 & 2 & 4
 \end{matrix} \Rightarrow \begin{bmatrix}
 3.25 & 4 & 4.5 \\
 2.5 & 2.875 & 3 \\
 2.125 & 2 & 1.75
 \end{bmatrix}$$

$$\begin{matrix}
 8 & 8 & 6 & 8 \\
 8.785 & 7.5 & 7.125 & 7 \\
 8 & 8.785 & 8 & 6 \\
 8.5 & 8.185 & 8 & 7.75 \\
 10 & 8 & 8 & 6
 \end{matrix} \Rightarrow \begin{matrix}
 7.785 & 7.5 & 7.125 \\
 8 & 7.825 & 8 \\
 8.125 & 8 & 7.75
 \end{matrix}$$

$$\begin{matrix}
 2 \\
 2 & 4 & 2 \\
 0 & 3 & 10 & 3 & 0 \\
 0 & 2.5 & 0 \\
 0
 \end{matrix} \Rightarrow \begin{matrix}
 2 & 4 & 2 \\
 3 & 10 & 3 \\
 0 & 2.5 & 0
 \end{matrix}$$